



General Maintenance for Washroom Accessories

Stainless Steel

Stainless steel responds well to cleaning, never wearing out from excessive cleaning, provided certain rules are followed:

1. Routine Cleaning

Use warm water and a cloth. Dry with a towel or cloth to prevent water spots. Wipe in the directions of the polish lines.

2. Tougher Cleaning

Mild detergent and warm water can do a great job without damaging the stainless steel. Make sure you rinse the surface thoroughly to prevent staining and spotting. The surface should be toweled dry to prevent water spots.

3. Cleaning Fingerprints

Fingerprints can be removed from stainless steel surfaces using glass cleaner or household ammonia. Rinse thoroughly and towel dry.

4. Polishing Stainless Steel

Stainless steel cleaners and polishes help minimize scratching and remove stains. Be sure to read the directions on the stainless cleaner and test in an inconspicuous spot. Always rinse thoroughly and towel dry.

Mirrors

Proper cleaning procedures must be followed to ensure the long-term performance of mirrors:

1. Routine Cleaning

Use a damp warm water cloth to clean glass and then dry the mirror immediately with a dry lint-free cloth.

2. Cleaners

Apply spray cleaners directly to a soft, lint-free cloth and then wipe the mirror. **Do not spray cleaners directly onto mirror. Do not use acid or alkali cleaners. Do not use any abrasive cleaners. Do not use cleaners that contain ammonia or vinegar.**

3. Removal of Stubborn Dirt and Surface Marks

To remove surface marks and/or stubborn dirt use 0000 oil-free steel wool, not solvents. Solvents can attack and damage the edges and backing of mirrors.

The Baby Stations (Fabricated From High-Density Polyethylene)

High-density polyethylene prohibits the retention of moisture and odors. Units are protected by Columbia Guard® an antimicrobial agent. Columbia Guard® protects against growth of microorganisms such as algae, bacteria, fungi and staph and reduces product deterioration due to premature degradation, odor, biofilm, discoloration and staining.

1. Routine Cleaning

Clean unit with mild detergent and warm water. Always rinse thoroughly and towel dry.

